

SONY[®]

Important information

PDT-FP1

Guidelines for safe and efficient use



The following instructions are for your own safety and to prevent device malfunction. If you aren't sure if your device is working properly, have the device checked by local authorized Sony service facility before use.



Warning

Risk of fire, explosion, electric shock, bodily injury or property damage may result if these instructions are not followed. Please read below information before using your device.

Taking care of and using your device

Warning

- Do not use a damaged device, such as a device with a cracked display or badly dented back cover, as it may cause injury or harm.
- Do not expose your device to fire or heat.
- When your device is not water resistant, avoid liquids entering the USB port, headset jack or any other slot of the device. Do not charge your device if water enters such ports. Please contact local authorized Sony service facility to investigate your device if water ingress occurs.
- Even if your device is water resistant, avoid that neither water containing impurities nor any other liquids (i.e. soft drinks, sea water, sweat, etc.) enter the USB port or any other slot of the device. Do not charge your device when such ports or slots are wet. You can charge your device after you dry and clean such ports or slots.
- Do not charge your device in wet areas or near a sink or a bathtub. Do not connect or disconnect the charger with wet hands.
- Regardless of the IP rating, avoid metallic objects or external agents like dust entering the USB port, headset jack or any other slot of the device. Clean out the ports before charging your device if metallic objects or external agents enter such ports.
- Do not apply strong force, heavy shock to your device. Dropping, bending, stepping on or throwing your device can cause battery damage. If you suspect there is damage to the battery, stop using the device and send it to a Sony service partner.
- Do not pierce your device with sharp objects.
- Avoid placing your device in tight fitting trouser pockets, as it may cause bending of the display and/or rear cover when you sit or move.
- Overheating can be caused if you are in contact with the device or the charger when operating or charging for long periods of time.
- Do not sleep with the device on your person or in your bed. Do not place the device under a blanket, pillow, or under your body, specially when connected to the charger, as this may cause the device to overheat.
- Charge your device where the device and the charger are in a well-ventilated area.
- Please note that the temperature may rise during continuous use or during charging. Also, be careful not to touch the device continuously and unintentionally by putting it in your clothes pocket or falling asleep. Continued direct contact with the device in this condition may cause low-temperature burns or other skin irritations.
- This product (including accessories) has magnet(s). Swallowing magnet(s) could cause serious harm, such as choking hazard or intestinal injuries. If magnets (or a magnet) were swallowed, consult a doctor immediately. Keep this product away from children or other supervised individuals to prevent accidental ingestion.
- Discontinue using your device, or disable the radio transmitting functionality of your device, where required or requested to do so.

For customers in the United States

- Batteries in this product must be replaced by local authorized Sony service facility. Please take care in disassembling or repairing the device. Please read any required service manuals before proceeding and follow all steps in the order in which they are described. If you do not have all tools and parts available to you, or are not comfortable performing the repairs described herein, do not proceed. Failure to follow these instructions, or use the proper tools and parts, may damage the battery, lead to personal injury or cause property damage.

For customers in other countries and regions

- Only local authorized Sony service facility should perform service procedures on your device. Do not attempt to disassemble or repair your device by yourself. It may cause device damage or bodily injury.
- Do not remove the back cover of your device as it may puncture the battery, causing bodily injury or device damage.

Note

- Treat the device with care and do not expose it to extreme high or low temperatures. Do not operate your device in temperatures below 0 °C (32 °F) or above 40 °C (104 °F).

- Careless or negligent handling of your device will void the terms of warranty.
- A rechargeable battery eventually wears out by repeat charging and discharging. This is not a defect and corresponds to normal wear and tear. When usage time becomes noticeably shorter, it is time to replace the battery.
- Minor variations in display brightness and color may occur between devices. There may be tiny bright or dark dots on the display. These are called defective pixels and occur when individual dots have malfunctioned and can not be adjusted. Two defective pixels are deemed acceptable.
- Minor variations in camera image appearance may occur between devices. Such variations are not uncommon and do not mean that a camera module is defective.
- Since the cellular system on which the device is to operate is provided by a carrier independent from Sony, Sony will not be responsible for the operation, availability, coverage, services or range of that system.
- Some of your personal settings, downloads and other information may be lost when your device is repaired or replaced. At present, Sony may be prevented by applicable law, other regulation or technical restrictions from making a backup copy of certain downloads. Sony does not take any responsibility for any lost information of any kind and will not reimburse you for any such loss. You should always make backup copies of all the information stored on your device, such as downloads, calendar and contacts, before handing in your device for repair or replacement.

Eyesight healthcare reminder (Taiwan)

Sony Corporation cares about you, please be sure to keep your eyes healthy, don't let eye strain happen. A friendly reminder: Excessive use may result in impaired eyesight. We recommend you to:

- 1 Take a 10 minute break after 30 minutes of usage.
- 2 Children under the age of two should not look at the screen, and those over the age of two should not look at the screen for more than one hour per day.

Charging

Warning

Use of chargers and USB cables other than Sony-branded may pose increased safety risks.

- Do not attempt to alter or modify the USB cable or the plug.
- Do not force the plug if it does not fit into a power outlet as this may result in electric shock.
- Only connect the charger to power sources as indicated on the device.
- Do not use the charger outdoors or in damp areas.
- Unplug the device before cleaning it to reduce the risk of electric shock.
- Remove the charger from the outlet by holding on to the adapter rather than the USB cable. Doing so reduces the risk of damage to the cable.
- Use a nearby wall outlet (wall socket) when using the AC Adapter/Battery Charger. If any malfunction occurs, disconnect the plug from the wall outlet (wall socket) immediately to disconnect from the power source.

Note

- Disconnect the power supply when the device is fully charged. When a power supply is connected, there is a small drain of power.
- Charge the battery in temperatures between 5 °C (41 °F) and 40 °C (104 °F).

Battery

Warning

For customers in countries and regions other than the United States

- Do not attempt to replace the battery yourself—you may damage the battery, which could cause overheating, explosion, fire, property damage or injury. The battery in your device must be serviced and recycled through local authorized Sony service facility.

Note

- New or idle batteries can have short-term reduced capacity. Fully charge the battery before initial use.

Memory card

If the device comes complete with a removable memory card, it is generally compatible with the device purchased but may not be compatible with other devices or the capabilities of their memory cards. Check

other devices for compatibility before purchase or use. If the device is equipped with a memory card reader, check the memory card compatibility before purchase or use.

Memory cards are generally formatted prior to shipping. To reformat the memory card, use a compatible device. For details, refer to the operating instructions of the device or contact the relevant Sony contact center.

Precautions regarding memory card use

- Do not expose the memory card to moisture.
- Do not touch terminal connections with your hand or any metal object.
- Do not strike or bend the memory card.
- Do not attempt to disassemble or modify the memory card.
- Do not use or store the memory card in humid or corrosive locations or in excessive heat conditions such as in a closed car in summer, in direct sunlight or near a heater, etc.
- Do not let dirt, dust, or foreign objects get into the memory card slot.
- Check that you have inserted the memory card correctly. The memory card may not operate properly unless fully inserted.
- We recommend that you make a backup copy of important data. We are not responsible for any loss or damage to content that you store on the memory card.
- Do not remove the memory card when the device is on. Recorded data may be damaged or lost if you remove it when the device is on.

SIM card

Do not insert a SIM card that is incompatible with your SIM card slot as it may damage your SIM card or your device permanently. If an adapter is required for insertion into your own or another device, do not insert the SIM card directly without the required adapter.

Note

Sony does not warrant and will not be responsible for any damage caused by use of incompatible or modified SIM cards.

Antenna

Use of antenna devices not marketed by Sony could damage the mobile device, reduce performance, and produce Specific Absorption Rate (SAR) levels above the established limits. Do not cover the antenna with your hand as this affects transmission quality and power levels, and can shorten usage times.

Potentially explosive atmospheres

Warning

It is rare, but your electronic device could generate sparks. Sparks in potentially explosive areas could cause an explosion or fire resulting in bodily injury or even death. Areas with a potentially explosive atmosphere are often, but not always, clearly marked.

- Turn off your device when in any area with a potentially explosive atmosphere.
- Do not use your device in a potentially explosive environment, such as a petrol station, oil depot, chemical factory or other flammable and explosive areas.
- Do not charge the device near to inflammable material as the heat can cause a fire.

Blasting areas

Warning

Turn off all your electronic devices when in a blasting area or in areas where the warning **“Turn off two-way radio”** is posted, to avoid interfering with blasting operations. Construction crews often use remote control RF devices to set off explosives.

Accessories

- Use only certified accessories. Sony does not test third-party accessories. Accessories may influence RF exposure, radio performance, loudness, electric safety and other areas. Third-party accessories and parts may pose a risk to your health or safety or decrease performance.
- Do not wear/use a Bluetooth® headset in such a way that you are uncomfortable or the device is subject to pressure.
- When you connect this product to a device with a USB cable, use a USB cable shorter than 3 m (9.8 ft).
- When you connect this product to a device with an HDMI cable, use an HDMI cable shorter than 3 m (9.8 ft).
- When you connect this product to a device with a LAN cable, use a Category 5e or higher Shielded Twisted Pair (STP) LAN cable shorter than 3 m (9.8 ft).
- Use Sony Fast charger XQZ-UC1 (not supplied) to charge your device.
The XQZ-UC1 specifications are as follows:
Input: AC100–240V 1.0A 50–60Hz
Output: 5.0V=3.0A / 9.0V=3.0A / 15.0V=2.0A
PPS: 3.3V=3.0A / 16.0V=1.85A
For more information on compatible Sony chargers, visit the Sony website.

Wired LAN

- To connect to the network of the device, establish a connection through a router or connect to a LAN port with the same function. Not establishing these kinds of connections may lead to security issues.
- For your safety, when connecting to peripheral devices, do not connect connectors that may have overvoltage to the LAN terminal.

Personal medical devices

Mobile devices and devices with radio transmitters may affect implanted medical equipment. Before using the device in close proximity to personal medical equipment, please consult a physician and the medical equipment manufacturer.

- Consult with authorized medical staff and refer to the instructions provided by the medical equipment manufacturer before using the device near pacemakers or other medical equipment.
- If you are in close proximity to a pacemaker or other medical equipment, or you are in a hospital, or you have a pacemaker or a cochlear implant, or you are using a hearing aid, please consult authorized physicians and refer to instructions from the medical equipment manufacturer before you use the device.
- Keep a minimum distance of 15 cm (6 in) between your device and the medical equipment to reduce the risk of interference.
- Turn off your device if you suspect interference.
- If you have a pacemaker, do not carry the device in your breast pocket.

This product (including accessories) has magnet(s) which may interfere with pacemakers, programmable shunt valves for hydrocephalus treatment, or other medical devices. Do not place this product close to persons who use such medical devices. Consult your doctor before using this product if you use any such medical device.

Driving

- In some cases, vehicle manufacturers may forbid the use of mobile devices in their vehicles unless a handsfree kit with an external antenna is used.
- Check with the vehicle manufacturer's representative to be sure that a mobile device or Bluetooth handsfree will not affect the electronic systems in the vehicle.
- Give full attention to driving at all times and follow local laws and regulations about the use of mobile devices while driving.
- Do not place your device, or install wireless equipment, in the area above an air bag in a car.
- Do not use GPS functionality in a manner which causes distraction from driving.

GPS/Location based functions

Some devices provide GPS/Location based functions. Location determining functionality is provided “As is” and “With all faults”. Sony does not make any representation or warranty as to the accuracy of such location information.

Use of location-based information by the device may not be uninterrupted or error free and may additionally be dependent on network service availability. Please note that functionality may be reduced or prevented in certain environments such as building interiors or areas adjacent to buildings.

Flight mode

Bluetooth and Wireless Local Area Network (WLAN) functionality, if available in the device, can be enabled in Flight mode but may be prohibited onboard aircraft or in other areas where radio transmissions are prohibited. In such environments, please seek proper authorization before enabling Bluetooth or WLAN functionality even in Flight mode.

Malware

Malware is software that can harm the device. Malware or harmful applications can include viruses, worms, spyware, and other unwanted programs. While the device does employ security measures to resist such efforts, Sony does not warrant or represent that the device will be impervious to the introduction of malware. You can, however, reduce the risk of malware attacks by using care when downloading content or accepting applications, by refraining from opening or responding to messages from unknown sources, by using trustworthy services to access the Internet, and by only downloading content to the mobile device from known, reliable sources.

Protection of personal information

Erase personal data before disposing of the device. To delete data, perform a factory reset. Deleting data from the memory of the device does not ensure that it cannot be recovered. Sony does not warrant against recovery of information and does not assume responsibility for disclosure of any information even after a factory reset.

Disposal of old electrical & electronic equipment (applicable in the European Union and other countries with separate collection systems)



This symbol on the product or on its packaging indicates that this product shall not be treated as household waste. Instead it shall be handed over to the appropriate collection point for the recycling of electrical and electronic equipment. By ensuring that this product is disposed of correctly, you will help to prevent potential negative consequences for the environment and human health, which could be caused by inappropriate waste handling of this product. The recycling of materials will help to conserve natural resources. For more detailed information about recycling of this product, please contact your local Civic Office, your household waste disposal service or the shop where you purchased the product.

Devices with 3D viewing capabilities

When viewing 3D images shot with a 3D viewing-capable device, you may experience discomfort in the form of eye strain, fatigue, or nausea when the images are viewed on a 3D-compatible monitor. To prevent these symptoms, we recommend that you take regular breaks. However, you need to determine for yourself the length and frequency of the breaks you require, as they vary according to the individual. If you experience any type of discomfort, stop viewing the 3D images until you feel better, and consult a physician as necessary. For additional information, refer to the operating instructions included with the 3D device or 3D software you are using with this device.

About RF exposure and Specific Absorption Rates (SAR)

RF exposure and Specific Absorption Rates (SAR)

SAR data information is provided for residents in countries that have adopted the SAR limits recommended by the International Commission on Non-Ionizing Radiation Protection (ICNIRP) or the Institute of Electrical and Electronics Engineers (IEEE). The ICNIRP specifies a SAR limit of 2 W/kg averaged over ten (10) grams of body tissue while the IEEE specifies a SAR limit of 1.6 W/kg averaged over one (1) gram of body tissue. These requirements are based on scientific guidelines that include safety margins designed to ensure the safety of all persons, regardless of age and health.

The SAR values and test distances differ depending on the measuring method, the device tested (phone or portable device) and if the Wi-Fi hotspot functionality is used, but only the highest SAR values are presented.

The WHO (World Health Organization) has stated that current scientific information does not indicate the need for special precautions regarding the use of phones and portable devices. For more information on this topic, please visit who.int/Home>Health Topics>E>Electromagnetic fields. Additional SAR-related information can also be found on the Mobile and Wireless Forum at <https://www.mwfai.org/>.

For more information about SAR and radio frequency exposure, go to: <https://www.sony.net/Products/smartphones/health-and-safety/sar.html>.

Export regulations

The device and accessories may be subjected to the export control laws and regulations.

In case of exporting or re-exporting the device and accessories, customers are responsible for complying with the necessary procedures at their own responsibility and cost. Please contact the competent authorities for details about procedures.

Trademarks

- The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Sony Group Corporation and their subsidiaries is under license.
- The terms HDMI®, HDMI High-Definition Multimedia Interface, HDMI Trade dress and the HDMI Logos are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.



Other product names, service names, company names or logo marks are trademarked and copyrighted properties of their respective owners and/or licensors.

Publication number

1.0

©2024 Sony Corporation