



KX-TCA60

Hands-Free Headset with Headband

This Accessory works with:

KX-TG7745S, KX-TG7732S, KX-TG7733S, KX-TG7622B, KX-TG7623B, KX-TG7642M, KX-TG7644M, KX-TG7645M, KX-TG7731S, KX-TG7741S, KX-TG7742S, KX-TG7743S, KX-TG7532B, KX-TG7643M, KX-TGA523M, KX-TGA400B, KX-TGA420B, KX-TG2970B, KX-TG2720S, KX-TG2750S, KX-TG2700S, KX-TG2382B, KX-TG2352W, KX-TG6702B, KX-TG6700B, KX-TG5110M, KX-TC1486B, KX-TG5576M, KX-TG5571M, KX-TG5566M, KX-TG5561M, KX-TGA520M, KX-TG4773B, KX-TG4771B, KX-TG4772B, KX-TG4032B, KX-TG4053B, KX-TG6545B, KX-TG6633B, KX-TG6572C, KX-TG6632B, KX-TG9472B, KX-TG9471B, KX-TG6671B, KX-TG6672B, KX-DT390-B, KX-TG6513B, KX-TG6511B, KX-TG6512B, KX-TG6645B, KX-TG9321T, KX-TG9322T, KX-TG2258S, KX-TG2740S, KX-TSC12W, KX-TG4000B, KX-TG6572R, KX-TG2267B, KX-TG5200M, KX-TG5202M, KX-TG2312W, KX-TG2313W, KX-TG2314W, KX-TG5210M, KX-TG5212M, KX-TG6591T, KX-TG6592T, KX-TG6641B, KX-TG6643B, KX-TG6644B, KX-TG2336S, KX-TG4031B, KX-TG4033B, KX-TG4034B, KX-TG5230M, KX-TG2343W, KX-TG2344B, KX-TG2346S, KX-TG5240M, KX-TC1703B, KX-TG2356S, KX-TG2357B, KX-TG6500B, KX-TG6502B, KX-TC1503B, KX-TC1503W, KX-TC1723B, KX-TG1000N, KX-TG2420B, KX-TG2420W, KX-TG2421W, KX-TG2422W, KX-TG5050W, KX-TG2431W, KX-TG2432B, KX-TC1743B, KX-TC1743W, KX-TG2000B, KX-TG6531B, KX-TG6532B

Tech Specifications

Connection	Standard 2.5mm
Microphone	Adjustable
Hands-free Usage	Yes
Reversible	Yes
Energy-efficient design	No
4-ft Cord	Yes
Ear-mount attachment	No
Adjustable Clothing Clip	No
Volume Control	No
Mute	No