

# Bosch Cooktop Over Built-in Oven Approved Combination Guide

**⚠ IMPORTANT:** When installing an oven in combination, a minimum distance between the ovens is required. Refer to the oven installation manual for all other measurements.

Appliances that are not listed must be approved under local codes and/or by the local authority having jurisdiction. For the latest updates to the approved oven/cooktop combination, refer to the website listed in your appliance's installation instructions.

Please note that gas cooktops may require a 3/8" street elbow (not provided) at the regulator outlet for installation above a built-in oven.

**OVENS, COOKTOPS, AND DRAWERS approved to be installed in combination and the installation has been certified by CSA:**

Built-in ovens   Fours encastrables		Cooktops   Tables de cuisson		
Conventional ovens   Four conventionnel	Steam ovens   Fours à vapeur	**Induction   Induction	**Electric   Électrique	Gas   Gaz
(1) HBLxxx1UC, HBLxxx3UC, HBLxxx4UC, HBNxxx1UC, HBLxxxx3T	(5) HSLPxxx1UC	NITxxx8UC, NITxxx9UC, NITxxx0UC, NITxxx8SUC, NITxxx9SUC, NITxxx0SUC	NEMxxx6UC, NETxxx8UC, NETxxx9UC, NETxxx8SUC, NETxxx9SUC	(1) NGMxxx6UC
(2) HBExxx1UC				(2) NGM5456UC, NGM5458UC, NGM5453UC, NGM3450UC
(3) HBExxx2UC				(3) NGMxxx7UC
				(4) NGMxxx8UC, NGMxxx1UC, NGMxxx0UC, NGMxxx9UC

\*\* Refer to product installation instructions.

\*\* Instructions d'install du produit de référence.

**OVENS, COOKTOPS, AND DRAWERS approved by BSH Home Appliances Corporation to be installed in combination. The suitability of the combination has not been evaluated by CSA:**

**Les FOURS, CUISINIÈRES ET TIROIRS suivants sont approuvés par BSH Home Appliances Corporation pour être installés en combinaison. Ces produits, identifiés dans le tableau ci-dessous, peuvent être installés en combinaison. La compatibilité de la combinaison n'a pas été évaluée par le CSA :**

Built-in ovens   Fours encastrables				Cooktops   Tables de cuisson		
Conventional ovens   Four conventionnel	Built-in microwaves   Micro-ondes encastré	Microwave drawers   Micro-ondes réchaud	Speed ovens   Four à cuisson rapide	**Induction   Induction	**Electric   Électrique	Gas   Gaz
(4) HBExxx3UC	(8) HMB5xxx2UC	(9) HMDxxx3UC, HMDxxx1UC	(6) HMCPxxx2UC, HMC8xxx2UC, HMC5015xUC	NITxxx8UC, NITxxx9UC, NITxxx0UC, NITxxx8SUC, NITxxx9SUC, NITxxx0SUC	NEMxxx6UC, NETxxx8UC, NETxxx9UC, NETxxx8SUC, NETxxx9SUC	(1) NGMxxx6UC
<b>Warming drawer   Tiroir-réchaud</b>	<b>Storage drawer   Tiroir de rangement</b>		(7) HMC54xx1UC, HMC54xx2UC			(2) NGM5456UC, NGM5458UC, NGM5453UC, NGM3450UC
(10) HWD5051UC, HWD5751UC, HWDxxx1UC	(11) HSD5051UC					(3) NGMxxx7UC
						(4) NGMxxx8UC, NGMxxx0UC, NGMxxx1UC, NGMxxx9UC

\*\* Refer to product installation instructions.

\*\* Instructions d'install du produit de référence.

# Guide de combinaison approuvé pour la table de cuisson sur four encastré Bosch

**⚠ IMPORTANT :** lors de l'installation combinée d'un four, une distance minimale entre les fours est requise. Reportez-vous au manuel d'installation du four pour toutes les autres mesures.

Les cuisinières qui ne sont pas énumérées ci-dessus doivent être approuvées en vertu des codes locaux et/ou par l'autorité locale compétente. Pour les dernières mises à jour de la combinaison approuvée du four/de la table de cuisson, reportez vous au site Web répertorié dans les instructions d'installation de votre appareil.

Les tables de cuisson à gaz peuvent nécessiter un coude de rue de 3/8 po (non fourni) à la sortie du régulateur pour une installation au-dessus du four encastré.

**Les FOURS, CUISINIÈRES ET TIROIR suivants sont approuvés pour une installation combinée et l'installation a été certifiée par la CSA :**

## Cooktop over built-in oven combination installation requirements

Reference the table below for dimensions. All dimensions are inches (mm). Refer to the product installation guide for all other measurements.

When installing an oven or oven with a drawer in combination with a cooktop, a minimum distance between the cabinet floor and countertop (B) is required.

## Installation de la combinaison de la table de cuisson sur le four intégré

Consultez le tableau ci-dessous pour dimensions. Dimensions en pouces (mm). Consulter le tableau pour les dimensions. Consulter le guide d'installation du four pour toutes les autres mesures.

Lorsque vous installez un four ou un four avec un tiroir en combinaison avec une table de cuisson, une distance minimale entre le dessous des armoires et le dessus du comptoir (B) est nécessaire.

Oven type   Type de four	Oven installation requirements   Exigences d'installation du four			**Cooktop installation requirements (min. wall spacing)   Exigences d'installation de la table de cuisson (espacement des murs min.)			
	A	B min.	C max.	(1)	(2)	(3)	(4)
(1) Conventional   conventionnel	28 <sup>1</sup> / <sub>4</sub> " (718)	31 <sup>1</sup> / <sub>4</sub> " (794)	4 <sup>3</sup> / <sub>4</sub> " (121)	D: 24" (610) E: 24" (610)	D: 3" (76) E: 4" (102)	D: 24" (610) E: 24" (610)	D: 16" (406) E: 16" (406)
(2) Conventional   conventionnel	23" (584)	27 <sup>3</sup> / <sub>4</sub> " (705)	8 <sup>1</sup> / <sub>4</sub> " (210)	D: 24" (610) E: 24" (610)	D: 3" (76) E: 4" (102)	D: 24" (610) E: 24" (610)	D: 16" (406) E: 16" (406)
(3) Conventional   conventionnel	23 <sup>1</sup> / <sub>16</sub> " (585)	27 <sup>13</sup> / <sub>16</sub> " (707)	8 <sup>3</sup> / <sub>16</sub> " (208)	D: 24" (610) E: 24" (610)	D: 3" (76) E: 4" (102)	D: 24" (610) E: 24" (610)	D: 16" (406) E: 16" (406)
(4) Conventional   conventionnel	23" (584)	27 <sup>3</sup> / <sub>4</sub> " (705)	8 <sup>1</sup> / <sub>4</sub> " (210)	D: 24" (610) E: 24" (610)	D: 3" (76) E: 4" (102)	D: 24" (610) E: 24" (610)	D: 16" (406) E: 16" (406)
(5) Steam oven   Four à vapeur	19 <sup>1</sup> / <sub>4</sub> " (488)	23 <sup>3</sup> / <sub>8</sub> " (594)	12 <sup>5</sup> / <sub>8</sub> " (321)	D: 24" (610) E: 24" (610)	D: 3" (76) E: 4" (102)	D: 24" (610) E: 24" (610)	D: 16" (406) E: 16" (406)
(7) Speed oven   Four rapide	17 <sup>3</sup> / <sub>4</sub> " (450)	22 <sup>1</sup> / <sub>2</sub> " (572)	13 <sup>1</sup> / <sub>2</sub> " (343)	D: 24" (610) E: 24" (610)	D: 3" (76) E: 4" (102)	D: 24" (610) E: 24" (610)	D: 16" (406) E: 16" (406)
(6 & 8) Microwave & speed oven   Micro-ondes & four rapide	19 <sup>1</sup> / <sub>4</sub> " (488)	24" (609)	12" (306)	D: 24" (610) E: 24" (610)	D: 3" (76) E: 4" (102)	D: 24" (610) E: 24" (610)	D: 16" (406) E: 16" (406)
(6 & 8) Microwave & speed oven with warming drawer (10)   Micro onde & four rapide avec tiroir chauffant	28 <sup>1</sup> / <sub>4</sub> " (718)	31 <sup>1</sup> / <sub>4</sub> " (794)	4 <sup>3</sup> / <sub>4</sub> " (121)	D: 24" (610) E: 24" (610)	D: 3" (76) E: 4" (102)	D: 24" (610) E: 24" (610)	D: 16" (406) E: 16" (406)
(9) Microwave drawer   Micro-ondes à tiroir	14 <sup>13</sup> / <sub>16</sub> " (376)	20" (508)	16" (406)	D: 24" (610) E: 24" (610)	D: 3" (76) E: 4" (102)	D: 24" (610) E: 24" (610)	D: 16" (406) E: 16" (406)

\*\* Refer to product installation instructions for all other installation dimensions.

\*\* Instructions d'install du produit de référence pour toutes les autres dimensions d'installation.

### Installation requirements | Exigences d'installation

