
INSTALLATION INSTRUCTIONS



Ceiling Column Mount



OMNDC46-55

A brand of 🛱 legrand

DISCLAIMER

Legrand | AV and its affiliated corporations and subsidiaries (collectively "Legrand | AV"), intend to make this manual accurate and complete. However, Legrand | AV makes no claim that the information contained herein covers all details, conditions or variations, nor does it provide for every possible contingency in connection with the installation or use of this product. The information contained in this document is subject to change without notice or obligation of any kind. Legrand | AV makes no representation of warranty, expressed or implied, regarding the information contained herein. Legrand | AV assumes no responsibility for accuracy, completeness or sufficiency of the information contained in this document.

Chief® is a registered trademark of Legrand AV Inc.

DEFINITIONS

MOUNTING SYSTEM: A MOUNTING SYSTEM is the primary Chief product to which an accessory and/or component is attached.

ACCESSORY: AN ACCESSORY is the secondary Chief product which is attached to a primary Chief product, and may have a component attached or setting on it.

COMPONENT: A COMPONENT is an audiovisual item designed to be attached or resting on an accessory or mounting system such as a video camera, CPU, screen, display, projector, etc.

WARNING: A WARNING alerts you to the possibility of serious injury or death if you do not follow the instructions.

CAUTION: A CAUTION alerts you to the possibility of damage or destruction of equipment if you do not follow the corresponding instructions.



installer's responsibility to make sure all mounting systems are properly assembled and installed using the instructions provided. WARNING: Failure to provide adequate structural strength for this mounting system can result in serious personal injury

or damage to equipment! It is the installer's responsibility to make sure the structure to which this mounting system is attached can support five times the combined weight of all equipment. Reinforce the structure as required before installing the mounting system.

WARNING: Exceeding the weight capacity can result in serious personal injury or damage to equipment! It is the installer's responsibility to make sure the combined weight of all components attached to the mounting system does not exceed 80 lbs (36.3 kg) for the OMNDC46 or 100 lbs (45.3 kg) for the OMNDC55.

WARNING: The OMNDC46/55 mounts were designed to be mounted to the UL-listed Chief® CPA395 ceiling mount. Do NOT attempt to mount to any other ceiling mount!


WARNING: Use this mounting system only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.


WARNING: Never operate this mounting system if it is damaged. Return the mounting system to a service center for examination and repair.

WARNING: Do not use this mounting system outdoors.

--SAVE THESE INSTRUCTIONS--

DIMENSIONS







LEGEND

	Tighten Fastener	Pencil Mark
	Apretar elemento de fijación	Marcar con lápiz
	Befestigungsteil festziehen	Stiftmarkierung
	Apertar fixador	Marcar com lápis
	Serrare il fissaggio	Segno a matita
	Bevestiging vastdraaien	Potloodmerkteken
	Serrez les fixations	Marquage au crayon
	Loosen Fastener	Drill Hole
	Aflojar elemento de fijación	Perforar
	Befestigungsteil lösen	Bohrloch
	Desapertar fixador	Fazer furo
	Allentare il fissaggio	Praticare un foro
	Bevestiging losdraaien	Gat boren
	Desserrez les fixations	Percez un trou
	Phillips Screwdriver	Adjust
Ð	Destornillador Phillips	Ajustar
	Kreuzschlitzschraubendreher	Einstellen
	Chave de fendas Phillips	Ajustar
	Cacciavite a stella	Regolare
	Kruiskopschroevendraaier	Afstellen
	Tournevis à pointe cruciforme	Ajuster
	Open-Ended Wrench	Remove
	Llave de boca	Quitar
64		Quitar Entfernen
ES.	Llave de boca	
ES O	Llave de boca Gabelschlüssel	Entfernen
A O	Llave de boca Gabelschlüssel Chave de bocas	Entfernen Remover
	Llave de boca Gabelschlüssel Chave de bocas Chiave a punte aperte	Entfernen Remover Rimuovere
	Llave de boca Gabelschlüssel Chave de bocas Chiave a punte aperte Steeksleutel Clé à fourche	Entfernen Remover Rimuovere Verwijderen Retirez
	Llave de boca Gabelschlüssel Chave de bocas Chiave a punte aperte Steeksleutel	Entfernen Remover Rimuovere Verwijderen Retirez Optional
	Llave de boca Gabelschlüssel Chave de bocas Chiave a punte aperte Steeksleutel Clé à fourche By Hand	Entfernen Remover Rimuovere Verwijderen Retirez Optional Opcional
	Llave de boca Gabelschlüssel Chave de bocas Chiave a punte aperte Steeksleutel Clé à fourche By Hand A mano	Entfernen Remover Rimuovere Verwijderen Retirez Optional
	Llave de boca Gabelschlüssel Chave de bocas Chiave a punte aperte Steeksleutel Clé à fourche By Hand A mano Von Hand	Entfernen Entfernen Remover Rimuovere Verwijderen Retirez Optional Opcional Opcional Opcional
	Llave de boca Gabelschlüssel Chave de bocas Chiave a punte aperte Steeksleutel Clé à fourche By Hand A mano Von Hand Com a mão	Entfernen Entfernen Remover Rimuovere Verwijderen Retirez Optional Optional Optional
	Llave de boca Gabelschlüssel Chave de bocas Chiave a punte aperte Steeksleutel Clé à fourche By Hand A mano Von Hand Com a mão A mano	Entfernen Entfernen Remover Rimuovere Verwijderen Retirez Optional Opcional Optional Opcional Opcional Opzionale
	Llave de boca Gabelschlüssel Chave de bocas Chiave a punte aperte Steeksleutel Clé à fourche By Hand A mano Von Hand Com a mão A mano Met de hand À la main	Entfernen Entfernen Remover Rimuovere Verwijderen Retirez Optional Optional Optional Optional Opzionale Optie En option
	Llave de boca Gabelschlüssel Chave de bocas Chiave a punte aperte Steeksleutel Clé à fourche By Hand A mano Von Hand Com a mão A mano Met de hand À la main Hex-Head Wrench	Entfernen Entfernen Remover Rimuovere Verwijderen Retirez Optional Opcional Opcional Opcional Optie En option Security Wrench
	Llave de boca Gabelschlüssel Chave de bocas Chiave a punte aperte Steeksleutel Clé à fourche By Hand A mano Von Hand Com a mão A mano Met de hand À la main Hex-Head Wrench Llave de cabeza hexagonal	Entfernen Entfernen Remover Rimuovere Verwijderen Retirez Optional Opcional Opcional Opcional Opcional Opzionale Optie En option En option Llave de seguridad
	Llave de boca Gabelschlüssel Chave de bocas Chiave a punte aperte Steeksleutel Clé à fourche By Hand A mano Von Hand Com a mão A mano Von Hand Com a mão A mano Met de hand À la main Hex-Head Wrench Llave de cabeza hexagonal Sechskantschlüssel	Entfernen Remover Rimuovere Verwijderen Retirez Optional Opcional Opcional Opcional Opcional Optie En option Security Wrench Llave de seguridad Sicherheitsschlüssel
	Llave de boca Gabelschlüssel Chave de bocas Chiave a punte aperte Steeksleutel Clé à fourche By Hand A mano Von Hand Com a mão A mano Met de hand À la main Hex-Head Wrench Llave de cabeza hexagonal Sechskantschlüssel Chave de cabeça sextavada	Entfernen Remover Rimuovere Verwijderen Retirez Optional Opcional Opcional Opcional Opcional Opcional Optie En option En option Security Wrench Llave de seguridad Sicherheitsschlüssel Chave de segurança
	Llave de boca Gabelschlüssel Chave de bocas Chiave a punte aperte Steeksleutel Clé à fourche By Hand A mano Von Hand Com a mão A mano Von Hand Com a mão A mano Met de hand À la main Hex-Head Wrench Llave de cabeza hexagonal Sechskantschlüssel Chave de cabeça sextavada Chiave esagonale	Entfernen Remover Rimuovere Verwijderen Retirez Optional Opcional Opcional Opcional Opcional Opcional Opcional Opcional Optie En option En option Security Wrench Llave de seguridad Sicherheitsschlüssel Chave de segurança Chiave di sicurezza
	Llave de boca Gabelschlüssel Chave de bocas Chiave a punte aperte Steeksleutel Clé à fourche By Hand A mano Von Hand Com a mão A mano Met de hand À la main Hex-Head Wrench Llave de cabeza hexagonal Sechskantschlüssel Chave de cabeça sextavada	Entfernen Remover Rimuovere Verwijderen Retirez Optional Opcional Opcional Opcional Opcional Opcional Optie En option En option Security Wrench Llave de seguridad Sicherheitsschlüssel Chave de segurança

TOOLS REQUIRED FOR INSTALLATION







Assembly And Installation

- Loosely attach two CPA395 ceiling plates (not included) to ceiling, following CPA395 installation instructions. Plates must be installed 25" apart for the OMNDC46 or 29.2" for the OMNDC55. Only install screws 3/4 of the way to allow for some adjustment after the display has been installed to columns. (See Figure 1)
- 2. Use CPA395 hardware (not included) to attach ceiling posts (A) to CPA395 plates. (See Figure 1)




Figure 1

3. Install two M8x20mm button head cap screws (D) loosely into two top holes on side of display. (See Figure 2)





Figure 2

- 4. Use installed screws (D) to hang display onto ceiling posts (A). (See Figure 3)
- 5. Tighten screws partially installed in Step 3.
- 6. Use two M8x20mm button head cap screws (D) to secure bottom of display to ceiling posts (A). (See Figure 3)





- 7. Tighten CPA395 ceiling plates to ceiling following CPA395 installation instructions.
- 8. Route cables as desired. See **Cable Management Section** for details.
- 9. Install top cover onto display. (See Figure 4)
- 10. Snap two pipe caps (C) into side covers. (See Figure 4)
- 11. Snap four bolt hole caps (B) into holes on side covers. (See Figure 4)





Figure 4

Cable Management

1. Route cables through ceiling posts (A) as desired. (See Figure 5)







A brand of Liegrand

8800-003157 Rev00 ©2019 Legrand | AV www.legrandav.com 08/19

Europe

Asia Pacific

- USA/International A 6436 City West Parkway, Eden Prairie, MN 55344
 - Ρ 800.582.6480 / 952.225.6000
 - **F** 877.894.6918 / 952.894.6918
 - A Franklinstraat 14, 6003 DK Weert, Netherlands
 - Ρ +31 (0) 495 580 852
 - F +31 (0) 495 580 845
 - A Office No. 918 on 9/F, Shatin Galleria 18-24 Shan Mei Street Fotan, Shatin, Hong Kong
 - **P** 852 2145 4099
 - F 852 2145 4477

