

CHRISTMAS TIME™

58" Dancing Santa



I saw mommy dancing with Santa Claus! Our African American dancing Santa, from Christmas Time, will have everyone dancing and spreading holiday cheer. Standing 58 inches tall, Santa carries his Naughty & Nice List and a toy sack filled with holiday goodies over his back.

When motion is detected, he will move his arms and sway his body to the song Jingle Bell Rock. Dressed in his famous red and white suit, his friendly face with open spectacles, round chubby cheeks, and soft curly beard will warm your heart. Place him in the foyer, near the fireplace, or next to the Christmas tree, and watch as everyone starts dancing.

- Motion sensor on the front of the base triggers dancing
- Animation switch and power jack on the back of the base
- Music speaker located on the top center of the base
- Adjustable music volume knob at the back of the base
- Dimensions: 15" D x 21" W x 58" H
- Assembly required - Collapsible for easy storage
- Recommended for indoor use only
- 1-year limited warranty

Model Number	UPC	Description
CT-ASC058-2RD1-AA	840148714366	58" African American Dancing Santa Claus with Naughty & Nice List and Toy Sack