

CHRISTMAS TIME™

36" Music and Motion Mrs. Claus



Who's busy baking cookies? Mrs. Claus from Christmas Time, that's who! Our Music and Motion Baking Mrs. Claus will fill your home, office, or shop with holiday cheer. Dressed in a festive white apron over a red velvet dress with a coordinating mob cap, her warm smile will add a whimsical touch to your holiday decor.

When you plug her in, she will move her head and arms with or without music, bringing joy to one and all. Standing 3 feet tall and holding a plate full of Christmas cookies, she will look cute near the Christmas tree, in your favorite display window, or greeting your guests in the foyer.

- Easy to operate - just plug it in to see movement
- Animated - moves head and arms with or without music
- Music on/off button is located under her left sleeve
- Jingle Bells can be heard through the music speaker
- Dimensions: 10" D x 16.5" W x 36" H
- Power Cord Length: 6-ft.
- No assembly required - simply fluff and enjoy
- 1-year limited warranty for indoor use

Model Number	UPC	Description
CT-MC036-2RD7	840148714502	3-Ft. Music and Motion Mrs. Claus with Apron and Christmas Cookies