

CPA-3310

PELLET DISPENSER BAG CLIP

Lift & Pour your wood pellets into the grill hopper with ease, then close spout cover to keep moisture out!

NEW
For
2023!

Flexible rubber lid seal allows for water resistance



Twin rubber blade seal keeps moisture out



Integrated bag seal cutter



- Hinged clamp design with various internal ribs to grab onto the plastic bag material, 2 ratchet style integrated clips to squeeze tightly and lock-on.
- Twin blade rubber seal is integrated into the top cap keeping moisture out when lid is closed.
- Can be used on all types of 10 to 40 lb. pellet poly style bags of wood pellets. (NOTE: Does not work with charcoal paper bags).
- Integrated bag seal cutter feature, so no need for scissors.
- Flip-up style cap with snap-lock feature keeps the lid fully open when pouring pellets out of nozzle.

Cuisinart
OUTDOORS