

KITCHENAID®

# CORDLESS VARIABLE SPEED HAND BLENDER

KHBBV83

## VARIABLE SPEED TRIGGER SWITCH

- Gives you greater flexibility and control over the recipe. The safety switch protects against accidental trigger movement.

## EASY TO CHARGE

- Charge from empty to full in 2 hours or less
- Quick Charge of 20 Minutes to make a Triple Berry smoothie or Tomato Basil Soup

## INCLUDES

- Blender arm (dishwasher-safe)
- 1 Liter BPA-free\* pitcher with lid (dishwasher-safe)
- BPA-free\* Chopper Attachment (dishwasher-safe)
- Pan Guard (dishwasher-safe)
- Charger

\*All materials that come into contact with food are BPA free



## AVAILABLE COLORS



BLACK  
MATTE



BLUE  
VELVET



CHARCOAL  
GREY



EMPIRE  
RED



ONYX  
BLACK



PASSION  
RED



WHITE

\* The NPD Group/Retail Tracking Service. U.S. dollar sales, 12 months ending February 2019.

\*\* US patent pending.

**KitchenAid®**