




AC600  
**Bladeless Tower Fan**  
.....  
**Operating Manual**



**This Fan is for residential use only.  
It is not intended to be used in commercial, industrial or agricultural settings.**



Rethinking Air Technology.

# READ AND SAVE THESE INSTRUCTIONS

**READ CAREFULLY BEFORE ATTEMPTING TO ASSEMBLE, INSTALL, OPERATE OR MAINTAIN THE PRODUCT DESCRIBED. PROTECT YOURSELF AND OTHERS BY OBSERVING ALL SAFETY INFORMATION. FAILURE TO COMPLY WITH INSTRUCTIONS COULD RESULT IN PERSONAL INJURY AND/OR PROPERTY DAMAGE!**

**RETAIN INSTRUCTIONS FOR FUTURE REFERENCE.**

## LASKO PRODUCTS, INC. LIMITED WARRANTY (VALID IN THE USA, ITS TERRITORIES, AND CANADA ONLY)

**WHAT THIS WARRANTY COVERS:** This product is warranted against defects in workmanship and/or materials.

**HOW LONG THIS WARRANTY LASTS:** This warranty extends only to the original purchaser of the product and lasts for one (1) year from the date of original purchase or until the original purchaser of the product sells or transfers the product, whichever first occurs.

**WHAT LASKO WILL DO:** During the warranty period, Lasko will, at its sole option, repair or replace any part or parts that prove to be defective or replace the whole product with the same or comparable model. For all warranty claims, the product must be returned to Lasko Products, Inc. at customer expense with proof of purchase within the warranty period. Contact the Lasko customer service department to obtain a Return Authorization ("RA"). DO NOT return products without an RA or the warranty claim will not be processed.

**WHAT THIS WARRANTY DOES NOT COVER:** This warranty does not apply if the product was damaged or failed because of accident, improper handling or operation, shipping damage, abuse, misuse, unauthorized repairs made or attempted. This warranty does not cover shipping costs for the return of products to Lasko for repair or replacement. Lasko will pay return shipping charges from Lasko following warranty repairs or replacement.

**ANY AND ALL WARRANTIES, EXPRESSED OR IMPLIED (INCLUDING, WITHOUT LIMITATION, ANY IMPLIED WARRANTY OF MERCHANTABILITY), LAST ONE YEAR FROM THE DATE OF ORIGINAL PURCHASE OR UNTIL THE ORIGINAL PURCHASER OF THE PRODUCT SELLS OR TRANSFERS THE PRODUCT, WHICHEVER FIRST OCCURS AND IN NO EVENT SHALL LASKO'S LIABILITY UNDER ANY EXPRESS OR IMPLIED WARRANTY INCLUDE (I) INCIDENTAL OR CONSEQUENTIAL DAMAGES FROM ANY CAUSE WHATSOEVER, OR (II) REPLACEMENT OR REPAIR OF ANY HOUSE FUSES, CIRCUIT BREAKERS OR RECEPTACLES. NOTWITHSTANDING ANYTHING TO THE CONTRARY, IN NO EVENT SHALL LASKO'S LIABILITY UNDER ANY EXPRESS OR IMPLIED WARRANTY EXCEED THE PURCHASE PRICE OF THE PRODUCT AND ANY SUCH LIABILITY SHALL TERMINATE UPON THE EXPIRATION OF THE WARRANTY PERIOD.**

Some states and provinces do not allow limitations on how long an implied warranty lasts, or the exclusion or limitation of incidental or consequential damages, so these exclusions or limitations may not apply to you. This warranty gives you specific legal rights. You may also have other rights which vary from state to state and province to province. Proof of purchase is required before a warranty claim will be accepted.

### CUSTOMER SERVICE:

Toll-Free (800) 233-0268. Email: [producthelp@airlogicproducts.com](mailto:producthelp@airlogicproducts.com)

Our Customer Service team is available to assist you with product and service questions, and replacement parts. They can be reached Monday through Friday, 8am-5pm Eastern. Please have your model number available, as well as the type and style (located on the underside of your product).

Customer Service Dept., 820 Lincoln Ave., West Chester, PA 19380  
(Please do not send product to this location)


[www.airlogicproducts.com](http://www.airlogicproducts.com)

PARTS FOR DISCONTINUED, OBSOLETE AND CERTAIN OTHER PRODUCTS MAY NOT BE AVAILABLE. DUE TO SAFETY REASONS, MANY ELECTRONIC COMPONENTS AND MOST FAN COMPONENTS ARE NOT AVAILABLE TO CONSUMERS FOR INSTALLATION OR REPLACEMENT.

Manual printed in China


Do you want efficient and enhanced support?  
Future product updates?

Register Your Product Today  
visit  
[www.airlogicproducts.com](http://www.airlogicproducts.com)  
Click on "Register Your Product"  
or  
scan with a smart phone



## The Air Logic® Story

A crisp piece of paper represents purity and vast potential. With proper engineering and imagination, it can become anything. In fact, knowing what to do, can even make it fly.



## The Air Logic® Commitment

Designed, developed and engineered in the U.S., Air Logic® products are intelligent and distinctively improved. We demand high quality, innovative design and simply smart thinking to offer the best air products for your home. We deliver the superior customer service and uncompromising safety standards you deserve. Guaranteed.

Air Logic® is part of Lasko Products, a U.S. company with over 100 years of experience in engineering and innovating home comfort products.

(Please Fly Responsibly  
Do not fly plane toward or at other people)

First Class  
Postage  
Required

Air Logic® Products  
Customer Service Department  
820 Lincoln Avenue  
West Chester, PA 19380

↑ ————— ↓  
Fold on line

↑ ————— ↓  
Fold on line

Place Serial Number Here

CUT HERE



**WARNING**



## IMPORTANT SAFETY INFORMATION

When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electrical shock and injury to persons, including the following:



Read all instructions before using this Fan.



### ⚠ WARNING

**TO REDUCE THE RISK OF FIRE, ELECTRICAL SHOCK OR PERSONAL INJURY, ALWAYS FOLLOW THESE IMPORTANT SAFETY INSTRUCTIONS AND WARNINGS:**



**DO NOT** use this fan to ventilate areas where flammable liquids or vapors are used, stored or are present, including paints, gasoline, varnishes, floor refinishing products or solvents. **ALWAYS** read and follow all warnings and instructions on the containers for these products!



**ALWAYS** be sure the plug fits tightly into the outlet. When plugs fit loosely into outlets, they may slip partially out of the outlet and create a poor connection. This may cause outlets to overheat and create a potential fire hazard. Outlets in this condition should be replaced by a qualified electrician.



**ALWAYS** unplug the power cord when servicing, cleaning or moving the Fan. **DO NOT** use the ON/OFF switch as the sole means of disconnecting power. **NEVER** leave children unattended when the Fan is on or plugged in. **ALWAYS** turn off and unplug the Fan when not in use.



**BE CERTAIN** that the power source for the Fan is 120V AC. **DO NOT** plug the Fan into 240V or other power source.



The **Blue Plug™** on your Lasko fan is a safety feature. It contains a non-replaceable safety device (fuse) that should not be removed or tampered with. To reduce the risk of fire, electric shock and personal injury, **DO NOT** attempt to remove, replace, repair or tamper with the originally supplied plug. If the Fan has stopped functioning, it may be due to the safety device incorporated in this plug. Call 800-233-0268, Monday - Friday, between 8:00 a.m. and 5:00 p.m. Eastern for questions. If the plug warning label is missing or damaged, call the toll free number for a replacement label.

**THIS FAN HAS A POLARIZED PLUG** (one blade is wider than the other). This plug is designed to fit into the outlet only one way. Match the wide blade to wide slot in outlet and **FULLY INSERT**. **DO NOT** attempt to bypass or defeat this safety feature. If the plug does not fit in the outlet, consult a qualified electrician. The outlet may need to be replaced.

### ⚠ CAUTION

- **AVOID** the use of extension cords, power strips, power taps, outlet style air fresheners or other cord connected device, as these devices may overheat and cause a fire hazard.
- **DO NOT** route power cord under rugs, carpets, runners or furniture. This may damage the cord or cause it to overheat creating a fire hazard.
- **ALWAYS** place the Fan on a stable, flat, level surface while in operation to prevent the Fan from overturning.
- **NEVER** insert or allow fingers or objects to enter grill openings while Fan is in operation or injury and/or damage to the Fan may occur.
- **DO NOT** block, cover or obstruct air flow to or from the fan while in operation.
- **DO NOT** use this Fan outdoors or near water or wet locations such as a bath tub, pool or hot tub. Use of this Fan in a wet location may create a shock hazard.
- **DO NOT** route power cord in or through areas such as doorways or where the cord may be damaged or create a tripping hazard.
- **NEVER** use a single extension cord to operate more than one Fan or other electrical device.
- **DO NOT** use this Fan in a window. Rain may create an electrical hazard.
- **DO NOT** use this Fan if it has been damaged or is not functioning properly.
- **DO NOT** operate any fan with a damaged cord or plug. Discard fan.
- **THIS FAN DOES NOT MEET THE REQUIREMENTS OF NEC ARTICLE 547-7 (2008).** This Fan is not suitable for use in agricultural facilities including areas where livestock, poultry or other animals are confined. Please refer to National Electric Code (NEC) Article 547-7 (2008), or applicable state or local codes or standards relating to electrical requirements for agricultural buildings.
- **THIS FAN DOES NOT MEET THE REQUIREMENTS OF NEC ARTICLE 500 (2008).** This Fan is not suitable for use in hazardous locations. Please refer to National Electric Code (NEC) Article 500 or applicable state or local codes or standards relating to electrical requirements for hazardous locations.

**NOTICE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help. The user is cautioned that changes and modifications made to the equipment without the approval of manufacturer could void the user's authority to operate this equipment.



# EZtouch™ Controls



Press the Power button to turn the Fan ON. The unit will turn on in High mode (4) by default. Press the Power button again to turn the Fan OFF.



The Speed button controls all fan speeds from 1-4. Speed 1 is Low and 4 is High. Press the Speed button to cycle between speeds.



Timer Mode allows you to set the length of time the Fan will run before turning itself off. Pressing the Timer button will increase the length of time from 1 to 8 hours, in 1 hour increments. Pressing the button again will turn off Timer Mode. After a few seconds, the unit will display the current Speed, as well as the Timer symbol.



Press the Oscillation Mode button to begin Oscillation. Press the button again to stop Oscillation.



Press the Fresh ion™ button to activate the release of positive and negative ions. The Fresh ion™ setting works in any speed mode. The fan must be on for the Fresh ion™ mode to operate. Press the Fresh ion™ button again to turn off Fresh ion™ mode.



## REGISTRATION REPLY CARD

### Air Logic® Cool Home Fan

Thank you for purchasing this Air Logic® Bladeless Fan, Model AC600. Air Logic® is a part of Lasko Products, Inc. Our ingenuity combined with a desire for innovative design, functionality and craftsmanship, allows us to see a vast potential in the air products you use in your home.

Please take a few minutes to fill out the information below or register online at <https://www.research.net/s/AirLogicCool>

Registering your product will help improve our future designs. It will also assist you if you should need service at a later date.

1.  Mr.  Mrs.  Ms.  Miss.  
 First Name \_\_\_\_\_ Initial \_\_\_\_\_ Last Name \_\_\_\_\_  
 Street \_\_\_\_\_ Apt. No. \_\_\_\_\_  
 City \_\_\_\_\_ State \_\_\_\_\_ Zip \_\_\_\_\_ Birth Year: \_\_\_\_\_

2. Date of Purchase/Receipt \_\_\_\_\_ / \_\_\_\_\_ / \_\_\_\_\_ Where Purchased? \_\_\_\_\_  
Month Day Year

3. This Fan is:  
 a replacement for another fan made by another company  
 a replacement for another Lasko® fan  
 the first fan you have ever owned  
 in addition to another fan(s) you are still using  
 Other (please specify) \_\_\_\_\_

4. Which statement below best describes you?  
 I always like buying a new technology as soon as it is available  
 I usually wait a short time before buying a new technology to make sure it gets good reviews  
 I never buy a new technology until I am sure it works well and the price is lower

5. Do you own any other Lasko® or Air Logic® Products?  
 Yes If Yes, How Many? Fans \_\_\_\_\_ Air Purifiers \_\_\_\_\_  
 No Heaters \_\_\_\_\_ Humidifiers \_\_\_\_\_

6. Where do you plan on using your fan? (Please select all that apply)  
 Living Room/Den  Kitchen  Basement  
 Dining Room  Home Office  Adult Bedroom  
 Children's Bedroom  Porch/Sunroom  Garage  
 RV/Camper  Work/Away from Home  Other \_\_\_\_\_

7. Which of the following had a major influence on your decision to purchase this product? (Select up to 3)  
 Fan Performance  Design  Price  
 Carton/Packaging  Previous Experience with Brand  Trusted Retailer  
 Consumer Reviews  Salesperson's Recommendation  Size  
 Brand Reputation  Family/Friend Recommendation  Color  
 Energy Savings Statements  Safety Features  Features/Function  
 Durability  Other \_\_\_\_\_

8. What other brand(s) did you strongly consider before purchasing this Air Logic® product?  
 Holmes  O2 Cool  Honeywell  
 Sunbeam  Feature Comforts  Bionaire  
 Aloha  Hunter  GE  
 Galaxy®  Coolmaster  Vornado  
 DeLonghi  Dyson  Black and Decker  
 Lasko®  None, I only consider Air Logic®  Other \_\_\_\_\_

9. We do **not** sell any customer information to 3rd parties. We do contact our customers, from time to time, to ask for new product ideas, or satisfaction with current products you own. Please provide an email address if you agree to receive future communications from Lasko® and Air Logic®.

Email Address: \_\_\_\_\_

(Please fold and tape before mailing.)

REMEMBER! You can register online at <https://www.research.net/s/AirLogicCool>

# Solución de Problemas

Si su Ventilador falla de operar, ver abajo para de causa y solucione probable: Esté seguro que la cuerda del poder se tapa en un trabajar salida eléctrica. Si usted tiene un problema que no puede ser la resolución por los pasos listó arriba,el contacto Ayuda Técnica en 1-800-233-0268, el lunes por el viernes, entre las horas de 8:00 de la mañana y 5:00 de la tarde. EST.

# Mantenimiento

**⚠️ ADVERTENCIA**

Para reducir el riesgo de choque eléctrico e incendio, por favor obedezca las siguientes instrucciones.

- Siempre desconecte el cable eléctrico antes de trasladar, reparar o limpiar.
- NUNCA coloque el Ventilador dentro de o cerca de agua.
- Limpie el Ventilador únicamente con una aspiradora equipada con un accesorio de cepillo; la aspiradora quitará el polvillo y los desperdicios del interior del Ventilador.
- NUNCA intente desarma el Ventilador.
- Limpie el cuerpo del Ventilador únicamente con un trapo suave.
- NUNCA use ALCOHOL o SOLVENTES tales como gasolina, bencina, disolvente para pinturas u otros limpiadores duros.

**REPARACIONES:** Para cualquier reparación, que no sea de mantenimiento general por parte del usuario, por favor contacte a nuestro equipo de Servicio al Cliente al (800) 233-0268 de Lunes a Viernes de 8 a.m. a 5 p.m.

**ALMACENAMIENTO:** Almacene el Ventilador con estas instrucciones, en la caja original en un lugar fresco y seco.

**LUBRICACION:** Los rodamientos estan lubricados permanentemente de por vida.

**DISPOSICIÓN:** Los materiales de empaque de cartón corrugado son reciclables. Para desechar este producto de manera ecológicamente responsable, comuníquese con su proveedor de servicio de desechos local o visite [www.1800recycling.com](http://www.1800recycling.com).

# Auto-Dimming Feature

The illuminated controls will go into Auto-Dimming Mode 10 seconds from the last button push. The reduction in brightness will keep the room darker during fan use. Once the controls are touched, the display will return to the original brightness. The Auto-Dimming Feature reduces the display brightness by 50%.



# Remote Control

All the functions performed with the Remote Control work identically to the EZtouch™ Controls. Remove battery cover before you install the two "AAA" batteries (Included). Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), rechargeable (nickel-cadmium), or lithium ion batteries. Replace battery cover.

# EZclick™ Filter System

Press the EZclick™ Filter button to release the cover for the washable filter. The washable filter can be cleaned with a vacuum, or removed and rinsed off with water. Clean the filter as needed, or every two weeks; this will help to maintain optimum filter performance. Remember to clean the filter before storing at the end of the season.



## Trouble Shooting

If your Fan fails to operate, see below for a probable cause and solution:  
Be sure the power cord is plugged into a working electrical outlet.  
If you have a problem that can not be resolved by the steps listed above, contact Technical Assistance at 1-800-233-0268, Monday through Friday, between the hours of 8:00 a.m. and 5:00 p.m. Eastern.

## Maintenance

### ⚠ WARNING

To reduce the risk of electrical shock and fire please observe the following instructions. Cleaning the Fan regularly will help to maintain its efficiency.



- Always unplug the cord before moving, servicing or cleaning.

- NEVER place the Fan in or near water.

- Clean the Fan only with a vacuum equipped with a brush attachment; the vacuum will remove the lint and dirt from inside the Fan.



- NEVER attempt to take apart the Fan.

- Clean the body of the Fan with a soft cloth only.

- NEVER use ALCOHOL or SOLVENTS such as gasoline, benzene, paint thinner, or other harsh cleaners.

**SERVICING:** For servicing, other than general user maintenance, please contact Customer Service at 800-233-0268, Monday through Friday, from 8am-5pm Eastern.

**STORAGE:** Store the Fan with these instructions in the original carton in a cool, dry place.

**LUBRICATION:** Motor is permanently lubricated.

**DISPOSITION:** Corrugated packaging materials are recyclable. For environmentally responsible disposal of this product, contact your local waste service provider or visit [www.1800recycling.com](http://www.1800recycling.com).

## Función de Graduación Automática

Los controles iluminados pasarán al Modo de Graduación Automática 10 segundos desde el momento en pulsar el último botón. La reducción en el nivel de brillo mantendrá la habitación más oscura durante el uso del ventilador. Una vez que se tocan los controles, la pantalla volverá al brillo original. La Función de Graduación Automática reduce el brillo de la pantalla en un 50%.



## Control Remoto

Todas las funciones realizadas con el control remoto operan de manera idéntica a los controles de EZtouch™. Quite cubierta de la batería antes de instalar las dos baterías "AAA" (incluidas). No mezcle las baterías viejas con las nuevas. No mezcle baterías alcalinas, estándar (carbón-zinc), recargables (níquel-cadmio) o baterías de iones de litio. Coloque la cubierta de la batería.

## Sistema de Filtro EZclick™

Pulse el botón del Filtro EZclick™ para liberar la cubierta del filtro lavable. El filtro lavable se puede limpiar con una aspiradora, o se puede remover y enjuagar con agua. Limpie los filtros según sea necesario o cada dos semanas; de esa manera, ayudará a mantener el desempeño óptimo del filtro. Recuerde limpiar el filtro antes de guardar la unidad al final de la temporada.

## Controles EZtouch™



Presione el botón de Encendido para encender el Ventilador. La unidad se encenderá en modo Alto (4) por defecto. Presione el botón de Encendido de nuevo para apagar el Ventilador.



El botón de Velocidad controla todas las velocidades del ventilador de 1 a 4. La velocidad 1 es Baja y la 4 es Alta. Presione el botón de Velocidad para cambiar de ciclo entre velocidades.



El Modo de temporizador le permite definir la cantidad de tiempo durante el cual operará el Ventilador antes de apagarse. Al pulsar el botón del Temporizador aumentará el tiempo de 1 a 8 horas, en incrementos de 1 hora. Si pulsa el botón de nuevo, desactivará el Modo de Temporizador. Después de unos segundos, la unidad mostrará la temperatura actual, así como el símbolo del Temporizador.



Pulse el botón de Modo de Oscilación para comenzar la oscilación. Pulse el botón de Modo de Oscilación de nuevo para detener la oscilación.



Presione el botón de Fresh ion™ para activar la liberación de iones positivos y negativos. La configuración de Fresh ion™ funciona en cualquier modo de velocidad. El Ventilador debe estar encendido para que funcione el modo de Fresh ion™. Presione el botón Fresh ion™ de nuevo para apagar el modo de Fresh ion™.



Rethinking Air Technology.

## AC600 Ventilador de Torre Sin Aspas Manual de Operación

**Este Ventilador es sólo para uso residencial.  
No está destinado para ser usado en instalaciones  
comerciales, industriales o agricultura.**



# LEA Y GUARDE ESTAS INSTRUCCIONES

LEA CUIDADOSAMENTE LAS INSTRUCCIONES ANTES DE INTENTAR ARMAR, INSTALAR, USAR O DAR MANTENIMIENTO AL PRODUCTO DESCRITO. PROTÉJASE A SÍ MISMO Y A LOS DEMÁS CUMPLIENDO CON TODA LA INFORMACIÓN DE SEGURIDAD.

EL NO SEGUIR LAS INSTRUCCIONES PODRÍA RESULTAR EN LESIONES PERSONALES Y/O DAÑOS A LA PROPIEDAD.

## GARANTÍA LIMITADA DE LASKO PRODUCTS, INC. (VÁLIDO EN EE.UU., SUS TERRITORIOS, Y CANADÁ ÚNICAMENTE)

**QUÉ CUBRE ESTA GARANTÍA:** Este producto está garantizado contra defectos de mano de obra y/o materiales.

**CUÁNTO DURA ESTA GARANTÍA:** Esta garantía se extiende únicamente al comprador original del producto y dura un (1) año a partir de la fecha original de compra o hasta que el comprador original del producto venda o transfiera el producto, cualesquiera de ambas que ocurriera en primer lugar.

**QUÉ HARÁ LASKO:** Durante el período de garantía, Lasko, a opción propia, reparará o reemplazará cualquier parte o partes que demuestren ser defectuosas o reemplazará el producto completo por el mismo modelo u otro comparable. Para todas las reclamaciones de garantía, se debe devolver el producto a Lasko Products, Inc. a cargo del cliente con la prueba de compra dentro del período de garantía. Comuníquese con el departamento de atención al cliente de Lasko para obtener una Autorización de Devolución ("RA", por sus siglas en inglés). NO devuelva los productos sin una RA o no se procesará la reclamación de la garantía.

**QUÉ NO CUBRE ESTA GARANTÍA:** Esta garantía no tiene validez si el producto fue dañado o falló debido a un accidente, manipulación u operación inadecuadas, daño en el envío, abuso, mal uso, reparaciones no autorizadas hechas o el intento de hacerlas. Esta garantía no cubre los costos de envío para la devolución de productos a Lasko para su reparación o reemplazo. Lasko abonará los cargos de envío de devolución a Lasko con posterioridad a las reparaciones o el reemplazo bajo garantía.

**CUALESQUIERA Y TODAS LAS GARANTÍAS, EXPLÍCITAS O IMPLÍCITAS (INCLUYENDO, SIN LIMITACIÓN, CUALESQUIERA GARANTÍA IMPLÍCITA DE COMERCIABILIDAD), DURAN UN AÑO A PARTIR DE LA FECHA ORIGINAL DE COMPRA O HASTA QUE EL COMPRADOR ORIGINAL DEL PRODUCTO VENDA O TRANSFIERA EL PRODUCTO, CUALESQUIERA DE AMBAS QUE OCURRIERA EN PRIMER LUGAR Y EN NINGÚN CASO LA RESPONSABILIDAD DE LASKO BAJO CUALQUIER GARANTÍA EXPLÍCITA O IMPLÍCITA INCLUIRÁ (I) DAÑOS INCIDENTALES O POR CONSECUENCIA POR CUALQUIER CAUSA QUE FUERE, O (II) REEMPLAZO O REPARACIÓN DE CUALESQUIERA FUSIBLES HOGAREÑOS, CORTA-CIRCUITOS O TOMACORRIENTES. INDEPENDIEMENTE DE CUALQUIER DECLARACIÓN CONTRARIA, EN NINGÚN CASO LA RESPONSABILIDAD DE LASKO BAJO CUALQUIER GARANTÍA EXPLÍCITA O IMPLÍCITA PODRÁ EXCEDER EL PRECIO DE COMPRA DEL PRODUCTO Y DICHA RESPONSABILIDAD TERMINARÁ AL VENCIMIENTO DEL PERÍODO DE GARANTÍA.**

Algunos estados y provincias no permiten limitaciones sobre la duración de una garantía implícita, o sobre la exclusión o limitación de los daños incidentales o por consecuencia, por lo tanto dichas exclusiones o limitaciones podrían no aplicarse en su caso. Esta garantía le otorga a usted derechos legales específicos. Usted también podría tener otros derechos que varían de estado en estado y de provincia en provincia.

Se requiere prueba de compra antes que se acepte un reclamo bajo garantía.

### SERVICIO AL CLIENTE:

Línea gratuita (800) 233-0268. Correo electrónico: [producthelp@airlogicproducts.com](mailto:producthelp@airlogicproducts.com)

Nuestro equipo de Servicio al Cliente está disponible para ayudarle con preguntas sobre productos, ubicaciones de los centros de reparación y repuestos. Se puede comunicar con nuestro equipo de Servicio al Cliente de lunes a viernes, de 8 a.m. a 5 p.m. hora del Este. Por favor tenga disponible el número de modelo, así como también el tipo y estilo (ubicados en la parte inferior de su producto).

Customer Service Dept., 820 Lincoln Ave., West Chester, PA 19380

(Por favor no envíe el producto a esta dirección)


[www.airlogicproducts.com](http://www.airlogicproducts.com)

**LOS REPUESTOS PARA PRODUCTOS DISCONTINUADOS, OBSOLETOS Y ALGUNOS OTROS PRODUCTOS PODRÍAN NO ESTAR DISPONIBLES. DEBIDO A RAZONES DE SEGURIDAD, MUCHOS COMPONENTES ELECTRÓNICOS Y LA MAYORÍA DE LOS COMPONENTES DE LOS VENTILADOR NO ESTÁN DISPONIBLES AL CONSUMIDOR PARA SU INSTALACIÓN O REEMPLAZO.**

El manual imprimió en la China

¿Desea un apoyo eficiente y mejorado?  
¿Futuras actualizaciones del producto?

Registre su producto hoy  
visite  
[www.airlogicproducts.com](http://www.airlogicproducts.com)  
Haga clic en "Registrar su producto"  
o  
escanee con un teléfono inteligente



## ADVERTENCIA



### INSTRUCCIONES IMPORTANTES DE SEGURIDAD

Al usar artefactos eléctricos, siempre deben tomarse precauciones básicas para reducir el riesgo de incendio, choque eléctrico y lesiones a personas:



Lea todas las instrucciones antes de usar este Ventilador.



### ADVERTENCIA



**NO** utilice este ventilador para ventilar las zonas donde se usen, almacenen o estén presentes líquidos o vapores inflamables, incluidos pinturas, gasolina, barnices, disolventes o productos de acabado para pisos. **¡SIEMPRE** lea y siga todas las advertencias e instrucciones descritas en los envases de estos productos!



**SIEMPRE** asegúrese de que el enchufe encaje bien en el tomacorriente. Cuando los enchufes no encajan bien en el tomacorriente, pueden deslizarse un poco y crear una mala conexión. Esto puede causar que los tomacorrientes se sobrecalienten y crear un riesgo de incendio potencial. Un electricista calificado debe cambiar los tomacorrientes que se encuentren en esta condición.



**SIEMPRE** desenchufe el cable de corriente cuando realice mantenimiento, limpieza o mueva el ventilador. **NO** use el interruptor ENCENDIDO/APAGADO (ON/OFF) como el único medio para desconectar de la electricidad. **NUNCA** deje a los niños sin supervisión cuando el ventilador esté encendido o conectado. **SIEMPRE** apague y desenchufe el ventilador cuando no esté en uso.



**ASEGURESE** que la fuente de energía para el ventilador sea de 120V AC. **NO** enchufe el ventilador en una fuente de energía de 240V ni en ninguna otra fuente de energía que no sea la indicada.



El **Blue Plug™** en su ventilador Lasko es una característica de seguridad. Contiene un dispositivo de seguridad no reemplazable (fusible) que no debe ser removido ni manipulado. Para reducir el riesgo de incendios, descargas eléctricas y lesiones, **NO** remueva, reemplace, repare ni manipule el enchufe suministrado originalmente. Si el ventilador no funciona adecuadamente, puede deberse al dispositivo de seguridad incorporado en este enchufe. Llame al 800-233-0268, de lunes - viernes, entre las 8:00 am y 5:00 pm del Este para las preguntas. Si la etiqueta de advertencia de enchufe se encuentra o está dañado, llame al número de teléfono gratuito para una etiqueta de reemplazo.

**ESTE ARTEFACTO TIENE UN ENCHUFE POLARIZADO** (una hoja del ventilador es más amplia que la otra). Este enchufe está diseñado para encajar en el tomacorriente de una sola forma. Haga coincidir la patilla ancha del enchufe con la ranura ancha del tomacorriente e **INSÉRTELA COMPLETAMENTE**. **NO** intente modificar o anular esta medida de seguridad. Si el enchufe no encaja en el tomacorriente, consulte a un electricista calificado. El enchufe puede necesitar ser reemplazado.

### PRECAUCIÓN

- **EVITE** el uso de cables de extensión, enchufes múltiples, triples, ambientadores eléctricos u otro dispositivo conectado por cables, ya que estos dispositivos pueden sobrecalentarse y causar un riesgo de incendio.
- **NO** coloque los cables de alimentación debajo de alfombras, tapetes o muebles. Esto puede dañar el cable o causar que se sobrecaliente y originar un riesgo de incendio.
- **SIEMPRE** colocar el ventilador en una superficie estable, plana y nivelada mientras esté funcionando para evitar que el ventilador se caiga.
- **NUNCA** inserte ni permita que introduzcan los dedos u objetos en las aberturas de la parrilla del ventilador mientras este esté en funcionamiento, ya que el ventilador puede dañarse o malograrse.
- **NO** bloquee, cubra ni obstruya el flujo de aire hacia o desde el ventilador mientras esté en funcionamiento.
- **NO** utilice este ventilador al aire libre o cerca del agua o lugares húmedos como bañeras, piscinas o jacuzzis. El uso de este ventilador en un lugar húmedo puede provocar una descarga eléctrica.
- **NO** coloque el cable de alimentación en o por áreas tales como puertas o donde el cable se pueda dañar o crear el peligro de que se tropiecen.
- **NUNCA** use un solo cable de extensión para hacer funcionar más de un ventilador u otro aparato eléctrico.
- **NO** use este ventilador en una ventana. La lluvia puede causar un peligro eléctrico.
- **NO** use este ventilador si es que se ha dañado o si no funcione adecuadamente.
- **NO** opere este ventilador si el cordón o clavija presentan daño. Deseche el ventilador.
- **ESTE VENTILADOR NO CUMPLE CON LOS REQUERIMIENTOS DEL ARTÍCULO 547-7 (2008) DEL NEC.** Este ventilador no es adecuado para su uso en instalaciones agrícolas, incluyendo las áreas donde el ganado, aves de corral u otros animales están encerrados. Consulte el Artículo 547-7 (2008) del Código Eléctrico Nacional (NEC) o los códigos o normas locales o estatales aplicables, relacionados con los requerimientos eléctricos para las instalaciones de agricultura.
- **ESTE ARTEFACTO NO CUMPLE CON LOS REQUISITOS DEL ARTÍCULO 500 DEL NATIONAL ELECTRICAL CODE (Código Eléctrico Nacional) 2008.** Este ventilador no es adecuado para uso en lugares peligrosos. Consulte el Artículo 500 del Código Eléctrico Nacional (NEC) o LOS CÓDIGOS O NORMAS LOCALES O ESTATALES APLICABLES, RELACIONADOS CON LOS REQUERIMIENTOS ELÉCTRICOS PARA LOS SITIOS PELIGROSOS.

**AVISO:** Este equipo ha sido probado y cumple con los límites para aparatos digitales Clase B, conforme a la Parte 15 de las Normas de la FCC. Estos límites están diseñados para brindar protección razonable contra la interferencia perjudicial en una instalación residencial. Este equipo genera, utiliza y puede irradiar energía de frecuencias de radio y, si no se instala y utiliza de conformidad con las instrucciones, puede causar interferencia perjudicial a las comunicaciones de radio. Sin embargo, no hay garantía de que la interferencia no ocurra en una instalación en particular. Si este equipo no causa interferencia perjudicial a la recepción de radio o televisión, lo cual se puede determinar al encender y apagar el equipo, el usuario puede intentar corregir la interferencia con una o más de las siguientes medidas: Reorientar o reubicar la antena receptora. Aumentar la separación entre el equipo y el receptor. Conectar el equipo en un tomacorriente de un circuito diferente a donde está conectado el receptor. Pedir ayuda al distribuidor o a un técnico experimentado de televisión y radio. Se informa al usuario que los cambios y las modificaciones realizadas al equipo sin la aprobación del fabricante pueden anular la autoridad del usuario de operar este equipo.