

All the pictures in this manual are for reference only, subject to our available products.

USB Camera | User Manual

Safety Warnings

Before using and operating this equipment, please read and observe the following precautions carefully to avoid dangerous or illegal operations.

♦ Placement

- DO NOT expose the camera to any heat source (such as electrical heater).
- 2) Normal operating temperature is 0–40 ℃, normal operating humidity is 10%–90%RH.
- DO NOT place the product in dusty and humid environments in case of internal circuit fault.
- The camera is not water–proof and dust–proof, do not expose the equipment directly to the sun, lest the equipment temperature is too high to affect the normal use of the equipment.

♦ Children Safety

The product and accessories may contain some small-part. Please place them beyond the reach of children in avoidance of swallowing danger.

Power Supply

1) Please use the standard cable of this product.

♦ Water Precaution

1) The product is not waterproof, Please keep it dry.

♦ Maintenance

- Please contact professional service personnel for maintenance services.
- When the equipment is damaged, please do not disassemble it for repair without permission, please call customer service to report for repair.
- without permission, piease can customer service to rep
- 3) DO NOT insert any sharp or pointed object into the device.4) DO NOT drop or hit the device to avoid damage to the device.

Statement


- Intellectual property right statement: The hardware design and software of this product are covered by the patents. Anyone who reproduces this product or the content of the instruction without the authorization of the Company shall assume legal liabilities.
- This manual is for reference only, and the actual function of the final product is subject to the actual function of the product received by the customer.
- 3) The picture is for reference only, please refer to the actual product. The company reserves the right to improve and change the appearance and design of the product without notice.

Accessories

USB cable × 1

1.Appearance Introduction

Please be familiar with the device interface and keys before use.





USB Camera b.Indicator Light d.Camera Bracket e.USB Type-C

2.Connection

Step 1: Please rotate the camera bracket to the direction to the back, as in the illustration.


Step 2: Please use the dedicated USB cable to connect the product with the personal computer.





3.Rotation

1) Support 360° Rotation



Support A Tilting Angle (≤10°)

