
Assembly Instructions for Chair

Caution : Please read instructions thoroughly before unpacking assembly parts. Sharp, exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staples used in packing.

- 1. We recommend that you should assemble this product with the assistance of another person ; this will make assembly easier, and will help to eliminate damage to the product or injury to persons during assembly.
- 2. Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.
- 3. Please do not over tighten screws or bolts.
- 4. Please put all parts on a non abrasive floor before assembly. and follow the assembly step to assemble your newly purchased product correctly and efficiently .



Assembly Instructions for Dining Table

Caution : Please read instructions thoroughly before unpacking assembly parts. Sharp, exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staples used in packing.

- 1. We recommend that you should assemble this product with the assistance of another person; this will make assembly easier, and will help to eliminate damage to the product or injury to persons during assembly.
- 2. Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.
- 3. Please do not over tighten screws or bolts.
- 4. Please put all parts on a non abrasive floor before assembly. and follow the assembly step to assemble your newly purchased product correctly and efficiently .

	PART LIST					
NO	PART DESCRIPTION	CODE	QTY			
A	TABLE HALF TOP		2			
В	EXTENSION LEAF		1			
C	LEG	DTLEG	4			

NO.	HARDWARE LIST		QTY
1	0	M8 x 70mm	8
2	Q	5/16"	8
3	Ô	5/16"IDx22mm	8
4	\sim	M5 x 65mm	1


HARDWARE LOCATED IN TABLE BOX

STEP 1

Remove discard wood block by lossen the screw with screw driver.(NOT PROVIDED)

STEP 2

Attach the table leg (C) to corner block table (A) with JCBB (1),Spring washer (2) and Flat washer (3) by using Allen Key (4). Repeat the same steps to fix the other three table legs.



STEP 3

1) Unlock the cam lock underneath the table top (A) by rotating the lock handle all the way the "off" marking on the cam locks and pull the table top wide open equally from both ends. Insert extension leaf (B) to center table and attach to location pin as shown.

2) Push the Table Top (A) from both ends to close and lock the cam lock underneath the table top by rotating the lock handle all the way to the "on" marking.

