

**Warranty
Registration:**
Register online today for
a chance to win a FREE
Tripp Lite product—
www.tripplite.com



1111 W. 35th Street, Chicago, IL 60609
Customer Support: (773) 869-1234
www.tripplite.com

Owner's Manual

Specialty Purpose Relocatable Power Taps (Power Strips for Medical Systems)



IMPORTANT SAFETY INSTRUCTIONS. SAVE THESE INSTRUCTIONS.

WARNING

1. Only use the Specialty Purpose Relocatable Power Tap (SPRPT) for supplying power to equipment that is intended to form part of the medical system.
2. The SPRPT shall be permanently attached to the medical system by a means such that it is only removable with the use of a tool. It shall not be located or positioned on the floor.
3. Do not use with any device that is not part of the medical system in which the SPRPT is installed. Do not connect equipment that is not part of the medical system to any unused SPRPT outlets. Do not touch parts of the SPRPT and the patient simultaneously. To remove power from the unit, disconnect using the plug cap. Do not pull on the supply cord.
4. The use of this SPRPT does not ensure that a medical system compliant with any standard or specifications (such as local codes) will result. Only those qualified to assemble a medical system shall attempt to do so.

The IEC 60601-1-1 standard is used to determine the suitability of a medical electrical system. In accordance with IEC 60601-1-1, in a medical system the medical equipment connections to the SPRPT shall only be accessible with the use of a tool. If you are not familiar with this standard and/or medical systems, do not use this device.

5. **Risk of Electric Shock:** Do not connect non-medical equipment that has been supplied as part of the medical system directly to a wall outlet when said non-medical equipment is intended to be supplied via a SPRPT with a separating transformer.
6. Use of this equipment in life support applications where failure of this equipment can reasonably be expected to cause the failure of the life support equipment or to significantly affect its safety or effectiveness is not recommended. Do not use this equipment in the presence of a flammable anesthetic mixture with air, oxygen or nitrous oxide.
7. The SPRPT shall be used within its marked load rating.

Lifetime Limited Warranty

Seller warrants this product, if used in accordance with all applicable instructions, to be free from original defects in material and workmanship for its lifetime. If the product should prove defective in material or workmanship within that period, Seller will repair or replace the product, in its sole discretion. Service under this Warranty can only be obtained by your delivering or shipping the product (with all shipping or delivery charges prepaid) to: Tripp Lite, 1111 W. 35th St., Chicago, IL 60609. Seller will pay return shipping charges. **THIS WARRANTY DOES NOT APPLY TO NORMAL WEAR OR TO DAMAGE RESULTING FROM ACCIDENT, MISUSE, ABUSE OR NEGLIGENCE. SELLER MAKES NO EXPRESS WARRANTIES OTHER THAN THE WARRANTY EXPRESSLY SET FORTH HEREIN. EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ALL IMPLIED WARRANTIES, INCLUDING ALL WARRANTIES OF MERCHANTABILITY OR FITNESS, ARE LIMITED IN DURATION TO THE WARRANTY PERIOD SET FORTH ABOVE, AND THIS WARRANTY EXPRESSLY EXCLUDES ALL INCIDENTAL AND CONSEQUENTIAL DAMAGES.** (Some states do not allow limitations on how long an implied warranty lasts, and some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you. This Warranty gives you specific legal rights, and you may have other rights which vary from jurisdiction to jurisdiction.)

TRIPP LITE; 1111 W. 35th St.; Chicago, IL 60609

WARNING: The individual user should take care to determine prior to use whether this device is suitable, adequate or safe for the use intended. Since individual applications are subject to great variation, the manufacturer makes no representation or warranty as to the suitability or fitness of these devices for any specific application.

WARRANTY REGISTRATION

Visit www.tripplite.com/warranty today to register the warranty for your new Tripp Lite product. You'll be automatically entered into a drawing for a chance to win a FREE Tripp Lite product!*

* No purchase necessary. Void where prohibited. Some restrictions apply. See website for details.

Regulatory Compliance Identification Numbers

For the purpose of regulatory compliance certifications and identification, your Tripp Lite product has been assigned a unique series number. The series number can be found on the product nameplate label, along with all required approval markings and information. When requesting compliance information for this product, always refer to the series number. The series number should not be confused with the marking name or model number of the product.

Tripp Lite follows a policy of continuous improvement. Product specifications are subject to change without notice.

200705295 93-2694