
INSTALLATION INSTRUCTIONS



Above-Tile Suspended Ceiling Storage Kit



CMA473

CMA473 Installation Instructions

DISCLAIMER

Milestone AV Technologies, and its affiliated corporations and subsidiaries (collectively, "Milestone"), intend to make this manual accurate and complete. However, Milestone makes no claim that the information contained herein covers all details, conditions or variations, nor does it provide for every possible contingency in connection with the installation or use of this product. The information contained in this document is subject to change without notice or obligation of any kind. Milestone makes no representation of warranty, expressed or implied, regarding the information contained herein. Milestone assumes no responsibility for accuracy, completeness or sufficiency of the information contained in this document.

Chief® is a registered trademark of Milestone AV Technologies. All rights reserved.




IMPORTANT SAFETY INSTRUCTIONS!

WARNING: A WARNING alerts you to the possibility of serious injury or death if you do not follow the instructions.



CAUTION: A CAUTION alerts you to the possibility of damage or destruction of equipment if you do not follow the corresponding instructions.



WARNING: Use this mounting system only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.

WARNING: Never operate this mounting system if it is damaged. Return the mounting system to a service center for examination and repair.

WARNING: Do not use this product outdoors.

IMPORTANT!: The CMA473 is compatible only with the CMA440 and CMS440 ceiling mounts. Do NOT attempt to install the CMA473 to any other mounting system!

IMPORTANT!: The CMA473 is not intended to support any weight. The total weight of the components within the CMA473 plus the weight attached to the CMA440 or CMS440 CANNOT exceed the weight limit of the CMA440 or CMS440. Weight capacity of CMA440 and CMS440 is 50 lbs (22.67 kg).


NOTES:

- It is the installer's responsibility to ensure that the enclosure is bonded to the ground in the switch box, in accordance with the National Electric Code, ANSI/ NFPA 70 or Canadian Electrical Code, CSA C22.1. A green grounding screw is provided in the enclosure for the purpose, if required.
- Spacings To ensure safe operation of the equipment installed in the enclosure, per National Electric Code ANSI/NFPA 70, a minimum separation between power cords and signal or communication cables may be required.
- This Cabinet System is for use with Listed ITE or Audio/ Video equipment only.

--SAVE THESE INSTRUCTIONS--


Installation Instructions CMA473

LEGEND






TOOLS REQUIRED FOR INSTALLATION




PARTS



CMA473 Installation Instructions

DIMENSIONS



Installation Instructions CMA473

INSTALLATION

WARNING: IMPROPER INSTALLATION CAN LEAD TO MOUNT FALLING CAUSING SEVERE PERSONAL INJURY OR DAMAGE TO EQUIPMENT! The equipment must be assembled and installed by qualified service personnel.

IMPORTANT!: The CMA473 is compatible only with the CMA440 and CMS440 ceiling mounts. Do NOT attempt to install the CMA473 to any other mounting system!

- Install CMA-440 or CMS-440 (accessory not included). See installation instructions included with the accessory.
- Install box (A) with four #10 X 3/8" Phillips tapping screws
 (B) (See Figure 1). Tighten securely.




Figure 1

NOTE: Box shown installed to CMS-440. CMA accessories similar.

Connect ground wire (not included) to grounding screws, if necessary. (See Figure 2)




Figure 2

NOTE: Knockouts are provided for ease of installation. All open knockouts need to be plugged, using 1/2" and 1 1/2" one-piece UL rated metal knockout seals which may be purchased at a hardware store.




Figure 3

CMA473 Installation Instructions

Cover Removal (Optional)

NOTE: Top cover may be removed during installation process if desired. However, it must be reinstalled before installation is complete!

- Remove four screws holding top cover to CMA473 box (A). (See Figure 4)
- 2. Lift top cover up from CMA473 box (A). (See Figure 4)




Figure 4

Installation Instructions CMA473

CMA473 Installation Instructions



Our Mounts. Your Vision.

Chief, a products division of Milestone AV Technologies

8800-002679 Rev00 ©2014 Milestone AV Technologies www.chiefmfg.com 11/14

Europe

USA/International A 6436 City West Parkway, Eden Prairie, MN 55344

800.582.6480 / 952.225.6000

F 877.894.6918 / 952.894.6918

Franklinstraat 14, 6003 DK Weert, Netherlands

+31 (0) 495 580 852

+31 (0) 495 580 845

Asia Pacific

Office No. 918 on 9/F, Shatin Galleria

18-24 Shan Mei Street

Fotan, Shatin, Hong Kong

852 2145 4099 852 2145 4477

