

24" FLUSH MOUNT DEFLECTOR VENT: **SKMD24FOAS / SKMD24FOAH** INSTALLATION INSTRUCTIONS


IMPORTANT NOTES TO THE INSTALLER

- Read all of the Installation Manual that is included with the Microwave Drawer before installing in the flush mount configuration.
- Observe all governing codes, ordinances, and safety instructions.
- Be sure to leave these instructions with the consumer.


Parts includes:

Part	SKMD24F0AS	SKMD24F0AH
	PREF-B019MRP0 Flush Mount Deflector Vent (Stainless steel) Qty. 1	PREF-B026MRP0 Flush Mount Deflector Vent (Dark gray) Qty. 1
()mmmmmm)	LX-CZB055MRE0 Mounting screws (Stainless steel) Qty. 2	LX-CZB073MRE0 Mounting screws (Black) Qty. 2

1. Prepare cabinet opening as shown in Figures 1, 2A, 2B, 2C.



- A. 6" (152.40 mm)
- B. Suggested electrical outlet location
- C. Anti-Tip block
- D. 5" (127 mm)
- E. 3-1/2" (88.90 mm)
- F. 4" (101.60 mm)
- G. 24-3/16" (614.35 mm) minimum 24-1/2" (622.3 mm) maximum
- H. 14-13/16" (376.24 mm) to bottom of Anti-Tip block
- I. 1-1/16" (26.97 mm)
- J. 23-1/2" (596.90 mm) minimum depth
- K. 22-1/8" (561.97 mm)
- L. 1-3/4" (44.45 mm)
- M. 16-7/8" (428.62 mm) opening
- N. Floor must support 100 lb (45.4 kg)
- O. 1-3/4" (44.45 mm)



- B. 1/4" (6.35 mm)
- C. 1-1/16" (26.97 mm)

Figure 2A

Top view

Note: the mounting surface of the finished cleat must sit $1^{1}/16$ " (26.97 mm) back

from the face of the cabinet [pushing the face of the drawer out 1 /4" (6.35 mm)].





Figure 2B

Front view

- A. 22-1/8" (561.97 mm) mounting cleat opening width
- B. 24-3/16" (614.35 mm) minimum 24-1/2" (622.3 mm) maximum flush opening width
- C. 3/4" (19.05 mm) shelf



2. Install deflector as shown in Figure 3A.

Shelf detail showing the deflector vent during installation. Position deflector vent and mark holes. Pre drill using a ½16" (1.57 mm) bit before mounting.




Figure 3A





Figure 3B

- 3. Place the drawer adjacent to the wall or cabinet opening. Plug the power supply cord into the electrical outlet.
- 4. Carefully guide the drawer into the prepared opening. Avoid contact with the sides of the cutout opening and also pinching the cord between the oven and the wall.
- 5. Slide the drawer all the way back until the mounting flanges touch the cleats mounted in the cabinet opening.
- 6. Open the drawer. Using the 4 holes on the drawer as a template, pre drill the cabinet using a 1/16" (1.57 mm) bit. See Figure 4.



7. Secure the drawer with the 4 screws supplied.

