## INSTALLATION INSTRUCTIONS

# FLAT CEILING PLATE WITH ADJUSTABLE EXTENSION COLUMN

### **CMA-100**

The optional CMA-100 column tube and ceiling plate are designed for attachment to the Chief ceiling mounts. The CMA-100 provides vertical adjustments in 3/4" increments when the column tube is telescoped over the ceiling plate tube and bolted through at the desired height.

#### WARNING: IMPROPER INSTALLATION MAY RESULT IN SERIOUS PERSONAL INJURY!

All components must be securely fastened to a structural member capable of supporting five times the combined weight of all components plus the equipment being mounted. If it cannot support this weight, the structure **MUST** be reinforced.

The maximum weight to be installed on the column is 500 pounds (226.8 Kg).

Unpack and check contents:

- (1) Column Tube
- (1) Ceiling Plate Tube
- (2) ½ 20 x 2½" Bolts
- (4) <sup>5</sup>/<sub>16</sub> 18 Socket Set Screws

- (2) 1/4 20 Nylock Nuts
- (4) 1/4" Flatwashers
- (1) <sup>5</sup>/<sub>32</sub> " Hex Wrench

#### INSTALLATION INSTRUCTIONS

- 1. Securely install the ceiling plate to the ceiling or ceiling joists (**NOTE: SEE WARNING!!**) Bolt hole spacing is shown on Figure 1.
- 2. Screw the column tube firmly into the ceiling mount collar.
- 3. Slide the column tube over the ceiling plate tube to the desired height and cross bolt with two ¼" bolts, nuts and washers provided. Make sure nuts and screws are tightened firmly. Install the four 5/16 18 set screws into the holes offset from the cross bolts.
- 4. Follow the ceiling mount instructions for installation and adjustment of the projector.



